



**X-Digital Systems XDS PRO4-P Receiver**  
**Network Configuration Data Sheet**  
**for Premiere Networks**

**C-Band Satellite:** SES Americom 18 (AMC-18)

- 105 Degrees West Longitude

**Transponder:** 21

- Downlink is Vertically polarized

**L-band receive frequency:** 01040500 kHz

**Symbol Rate:** 07136000 sps

**Affiliate Web Site:** <http://myXDSreceiver.PremiereRadio.com>

(To set up receiver program schedule, map relay ports, and other features)

**NOTES:**

1. Your Premiere Networks XDS PRO4-P receiver must be connected to a full-time internet connection
2. Please refer to the Quick Start Manual for installation instructions.
3. Your XDS PRO4-P receiver will only work on the Premiere Networks carrier. View the LCD display for the Model type.

**FOR TECHNICAL ASSISTANCE CALL:**

**Premiere Networks Technical Services**

1. (818) 461-5176 : Monday to Friday 8:30am - 5:30pm PT
2. email : PRN-XDSHelp@iheartmedia.com

**FOR PROGRAM SHOW CLOCKS:**

1. Website: <http://engineering.premiereradio.com/>
2. To view Clocks – High Resolution Clocks
3. To view a of list of Premiere Network Show Clocks